

## MW801 PRO

PRODUCT  
Image  
Unavailable

PRODUCT  
Image  
Unavailable



PRO Portable pH / Conductivity / TDS Combination Meter

Rating: Not Rated Yet

[Ask a question about this product](#)

### Description

**MW801 PRO Portable pH / Conductivity / TDS Combination Meter**

3 meters in 1! This meter allows you to measure pH, EC (conductivity) and TDS with just one instrument and one single probe!

The MW801 with a Conductivity range that goes up to 1990  $\mu\text{S}/\text{cm}$  and TDS range that goes up to 1990 ppm is an ideal tool for drinking water measurements.

Supplied with the SE600 interchangeable probe to measure pH, Conductivity and TDS. The pH electrode utilizes a fiber junction to reduce contamination when measuring fertilizer solutions. Both meters calibrate manually in pH, Conductivity and TDS.

**Accessories:**

- **M10004B** pH 4.01 buffer solution 20 ml sachet (25 pcs)
- **M10007B** pH 7.01 buffer solution 20 ml sachet (25 pcs)
- **M10010B** pH 10.01 buffer solution 20 ml sachet (25 pcs)
- **M10031B** 1413  $\mu\text{S}/\text{cm}$  calibration solution, 20 ml sachet (25 pcs)
- **M10032B** 1382 ppm calibration solution, 20 mL sachet (25 pcs)
- **MA9015** Electrode storage solution, 230 ml bottle
- **SE600** pH/EC/TDS spare probe with 1 m cable

**Ordering information:**

MW801 is supplied complete with SE600 combination pH/EC/TDS probe, 20 mL sachet pH 7.01 buffer solution, 20 mL 1413  $\mu\text{S}/\text{cm}$  sachet of calibration solution, 20 mL 1382 ppm sachet of calibration solution, 9V battery and instructions.