

MW102-FOOD

PRODUCT
Image
Unavailable

MW102-FOOD



Portable pH/Temperature Meter for Dairy Products

Rating: Not Rated Yet

[Ask a question about this product](#)

Description

MW102-FOOD Portable pH/Temperature Meter for Dairy Products (Milk, Cream, Yogurt) and Liquid Food, supplied with MA920B/1 pH open junction electrode and Temp. probe

MW102 is a microprocessor based pH/Temperature meter with extended range (-2.00 to 16.00 pH), Automatic Temperature Compensation, automatic calibration in 2 points and ± 0.02 pH accuracy.

The kit contains MW102 meter with MA920B/1 special pH electrode for food application complete in MA751 hard carrying case with calibration solutions.

Accessories:

- **MA920B/1** pH electrode with BNC connector and 1 m cable for food application
- **M10004B** pH 4.01 buffer solution 20 ml sachet (25 pcs)
- **M10007B** pH 7.01 buffer solution 20 ml sachet (25 pcs)
- **M10010B** pH 10.01 buffer solution 20 ml sachet (25 pcs)
- **MA9004** pH 4.01 buffer solution, 230 ml bottle
- **MA9007** pH 7.01 buffer solution, 230 ml bottle
- **MA9010** pH 10.01 buffer solution, 230 ml bottle
- **MA9015** Electrode storage solution, 230 ml bottle
- **MA9016** Electrode cleaning solution, 230 ml bottle
- **M10000B** Electrode rinse solution, 20 ml sachet (25 pcs)
- **MA830R** Temperature probe

Ordering information:

MW102-FOOD is supplied complete in hard carrying case with a MA920B/1 pH electrode, MA830R stainless steel temperature probe, pH 7.01 20 mL sachet of calibration solution, 9V battery and instructions.