

## pH56 PRO

PRODUCT  
Image  
Unavailable

PRODUCT  
Image  
Unavailable



PRO pH / Temperature Meter with replaceable electrode

Rating: Not Rated Yet

[Ask a question about this product](#)

### Description

**pH56 PRO Pocket-size pH / Temperature Meter with replaceable electrode**

IP65 Waterproof pH tester with Large dual-level LCD that displays pH and temperature (°C or °F). The large display shows readings in an extended range from -2.00 to 16.00 pH (with a 0.01 pH resolution) and simultaneously shows temperature from -5.0 to 105.0°C or 23.0 to 221.0°F.

pH56 has a stability indicator and hold function that freezes the display for easy and accurate recording. The large display also has graphic symbols to guide you through all operations. Complete with a temperature probe for faster and more precise temperature measurement it compensates automatically for temperature.

Calibration is made automatically in 1 or 2 points with memorized standard and NIST buffer sets. Auto power OFF saves battery power after non-use. The double-junction electrode can be replaced in a very fast and simple way! The modular design allows easy electrode and battery replacement.

**Accessories:**

- **Mi56P** Replaceable electrode for pH55 & pH56
- **M10004B** pH 4.01 buffer solution 20 mL sachet (25 pcs)
- **M10007B** pH 7.01 buffer solution 20 mL sachet (25 pcs)
- **M10010B** pH 10.01 buffer solution 20 mL sachet (25 pcs)
- **MA9004** pH 4.01 buffer solution, 230 mL bottle
- **MA9007** pH 7.01 buffer solution, 230 mL bottle
- **MA9015** Electrode storage solution, 230 mL
- **MA9016** Electrode cleaning solution, 230 mL
- **M10000B** Electrode rinse solution, 20 mL (25 pcs)

**Ordering information:**

pH56 is supplied complete with protective cap, 20 mL pH 4.01 and pH 7.01 sachets of calibration solution, batteries and instructions in a plastic tube.